


QUIK SERIES SOFTWARE

Steel Detailing Services
Building Design and Documentation
Steel Detailing Software Development

How to Install 'Quik Series Software'

- Please ensure you have '*Administrator Access*' before proceeding with the installation. This is essential for a smooth installation.
- Place the CD into your computers CD-Drive, after a small delay the auto start will initiate. If the auto start does not initiate, then go to '*Windows Explorer*', and select '*Setup.exe*' located on the CD's route drive.
- The installation will proceed in three stages. The first stage copies the '*IntelliCAD*' installation and the '*Quik Series*' installation to your computers temporary folder. The second stage of the installation installs the '*IntelliCAD*' component, with the third stage installs the '*Quik Series*' component.



- On each stage of the installation, either fill in the appropriate fields or click on the appropriate buttons in the installation softwares dialog box.
- When installing the '*IntelliCAD*' component, you may enter the '*IntelliCAD*' authorization number, or you can just select '*Trial Version*' and enter the authorization at a later date. The '*Trial Version*' will run for 30 days without this number
- At the completion of the '*IntelliCAD*' component, the user is prompted by a dialog box similar to box shown left. It is recommended that the '*Create a shortcut on the Desktop*' option is ticked.
- If you miss making the shortcut, you can add the shortcut later on through the '*Windows Explorer*' by right clicking on the '*Icad.exe*' file and selecting '*Create Shortcut*'.
- On completion of all three stages, the user is prompted to restart the computer. This is always recommended.

ABN 34 336 297 554
122 Salamander Way
Salamander Bay 2317
Phone (61) 249847377
Fax (61) 249820950
Email mail@rcassoc.com.au




QUIK SERIES SOFTWARE

Steel Detailing Services
Building Design and Documentation
Steel Detailing Software Development

Initial Start-up of 'Quik Series Software'

- When 'Quik Series' initially starts up, the user is prompted for an 'Authorization Number', without this



number must sections of the software will not operate correctly or operate at all

- In order to give the 'Authorization Number' the 'Reference Number' is required. The 'Reference Number' is given in the third field down
- To get an 'Authorization Number' you should email the 'Reference Number' to support@rcassoc.com.au
- An 'Authorization Number' will be issued and returned to you via email with in a 48 hours period, unless prior arrangements have been made
- Unfortunately the software contained on the installation disks is usually always out of date. To combat this it is recommended that after the initial start-up is complete, that an upgrade is applied
- If your system has been created specially for your company, then customised data files will be used. These customized data files are not included in the normal installations and need to be installed separately. To do this please refer to the notes below

How to Upgrade Quik Series Software

- Close or shutdown IntelliCAD
- Go to website location http://www.rcassoc.com.au/index_files/Upgrade.htm
- Download latest upgrade and save to a location on your hard disk
- After download is complete, run the upgrade file that was just downloaded
- Operation complete. Start IntelliCAD, and press the F2 key. The new version number should now be visible

Installing Custom Data Files

- These files are normally supplied by email in the WinZip format
- Close or shutdown IntelliCAD
- Open the relevant zip file with WinZip
- Extract to the 'IQframe\Library' folder
- Operation complete.

ABN 34 336 297 554
122 Salamander Way
Salamander Bay 2317
Phone (61) 249847377
Fax (61) 249820950
Email mail@rcassoc.com.au

